

5Tech Edge Bridge (ESP32) — Phase-1 MVP — User & Operation Manual

Setup, flashing, Wi-Fi / MQTT configuration, Bluetooth LE commands, and the demo flow for the ESP32 Edge Bridge.

esp32-edge-bridge · Revision Draft (Preliminary) · 2026-07-08 · Status: **PRELIMINARY**

PRELIMINARY. This manual describes a Phase-1 MVP on an off-the-shelf ESP32 development board. It is a **monitoring and automation prototype**, not a finished or certified product. Procedures and values marked [TBD] are pending confirmation. The authoritative engineering documents are in [modules/5tech-edge-iot-bridge/](#); always follow the docs shipped with the firmware you flashed.



ESP32 dev board

SENSORIUM™

5Tech Edge IoT Bridge

Industrial Hero Render.

Figure FIG-001 — 5Tech Edge Bridge, the Phase-1 MVP that bridges an input to an automation flow over Wi-Fi, Bluetooth LE, and MQTT.

1. Safety

Read this chapter before you set up, operate, or modify the Edge Bridge.




Figure FIG-002 — Signal words (*DANGER · WARNING · CAUTION · NOTICE*) and the pictograms used in this manual.

1.1 Signal words

SIGNAL WORD	MEANING
DANGER	Hazard that will cause death or serious injury if not avoided.
WARNING	Hazard that could cause death or serious injury if not avoided.
CAUTION	Hazard that could cause minor or moderate injury if not avoided.
NOTICE	Practice not related to personal injury — property or equipment damage, or an important advisory (scope / limitation) the reader must heed.

1.2 This is not a safety device

NOTICE — Not a safety device. The 5Tech Edge Bridge is a **monitoring and automation prototype** on a development board. It carries **no safety certification of any kind** and must **not** be used to protect people or equipment, to stop machinery, to create a protective zone, or as any part of a functional-safety function. Its hazard states (**WARNING** / **DANGER**) are demonstration signals in a data pipeline, not safety outputs. Never rely on it where a failure could cause injury or loss. *(This is a scope advisory about what the device is not — a **NOTICE** per §1.1, not a hazard warning about the device itself.)*

1.3 Intended use and audience

The Edge Bridge is intended for use **by developers, technicians, and integrators on a trusted test bench** to validate the sensor-to-automation pipeline and to demonstrate it to clients and stakeholders. Any other use — in particular field deployment, safety use, or connection to an untrusted network — is considered misuse for this Phase-1 MVP.

1.4 Qualified personnel and required competency

Set-up, operation, wiring, and modification of the Edge Bridge are for **qualified personnel** only. For this Phase-1 MVP that means a person who:

- is a **developer, technician, or integrator** competent in low-voltage electronics and ESD-safe handling of a bare PCB;
- can flash firmware and read a serial console, and understands 3.3 V logic and that the GPIO pins are **not** 5 V tolerant (§1.5);
- understands MQTT / Bluetooth LE on a trusted LAN and the plaintext, unauthenticated nature of this prototype (§1.7);
- and, before wiring anything to the **Con1** output or the **Det1** / **Det2** inputs, can confirm the external circuit's voltage, current, and isolation against the datasheet.

A person without this competency must not set up, wire, or modify the device unsupervised.

1.5 Electrical safety

The board is powered from a **USB 5 V** source and operates at low voltage (3.3 V logic). Electrical-shock risk from the board itself is minimal, but:

NOTICE — Equipment damage. GPIO pins are **3.3 V logic and are not 5 V tolerant**. Applying more than 3.3 V to a GPIO input, shorting pins, or reversing a connection can

destroy the board. Power the board from one source at a time (USB *or* an external 3.3 V/5 V rail, not both). Observe ESD precautions when handling the bare board.

- Use a data-capable USB cable and a known-good USB port or supply.
- If you connect an external sensor or a load to the `Con1` output, confirm its voltage and current are within the pin's rating (`[TBD]`) before wiring. Do not switch mains or an inductive load directly from a GPIO pin.

1.6 Radio-frequency (RF) note

The board transmits on **Wi-Fi (2.4 GHz)** and **Bluetooth LE** through the module's onboard antenna. Transmit power is low and typical of a consumer ESP32 module. Regional radio approvals for the *assembled prototype* are `[TBD]` — this is a development device, so operate it only where such use is permitted and keep it on a trusted bench network.

1.7 Residual risks

Even when used as intended, the following remain: the device may **latch a hazard state** and keep reporting `DANGER` after a sensor recovers (this is deliberate — see §3.3); on a plaintext network anyone who can reach the broker can command the device; and Bluetooth LE and Wi-Fi share one antenna, so BLE responsiveness varies with Wi-Fi load. None of these is a safety mitigation.

2. About this manual

Scope. This manual covers setting up, flashing, configuring, operating, and troubleshooting the Edge Bridge Phase-1 MVP on an ESP32 development board. It does **not** replace the detailed engineering documentation in the firmware repository.

Audience. Developers, technicians, and integrators as described in §1.3.

Conventions.

- Safety notices use the signal words in §1.1 and appear **before** the step they apply to.
- Procedures are numbered, one action per step.
- `[TBD]` marks a value pending confirmation. Never substitute a guessed value for a `[TBD]`.
- `Monospace` denotes commands, file names, pin names, topics, and UI/console text.

Related documents.

DOCUMENT	LOCATION	USE
Datasheet	datasheets/esp32-edge-bridge-datasheet/	Dev-board specs, interfaces, pinout, ratings
Product overview	products/esp32-edge-bridge/	Positioning and highlights
Firmware — setup	modules/5tech-edge-iot-bridge/docs/setup.md	Toolchains, secrets, build, flash
Firmware — MQTT API	modules/5tech-edge-iot-bridge/docs/mqtt-api.md	Topics and payload schemas
Firmware — Bluetooth API	modules/5tech-edge-iot-bridge/docs/bluetooth-api.md	GATT table, BLE commands
Firmware — demo script	modules/5tech-edge-iot-bridge/docs/demo-script.md	The client / investor walkthrough

3. Product overview & theory of operation




Figure FIG-003 — The Edge Bridge and its connections: USB, optional inputs, and the two 2.4 GHz

radios.

3.1 What it does

The Edge Bridge reads an input, decides whether that input represents a `WARNING` or `DANGER` condition, and republishes the decision as structured JSON over Bluetooth LE and MQTT so that an automation flow can act on it. It runs on a stock ESP32 dev board and needs no sensor hardware to demonstrate.

3.2 Where it sits — Sense → Connect → Decide

- **Sense** — a GPIO sensor (Det1 / Det2), the onboard button, a simulated sensor, or a remote command indicates a condition.
- **Connect** — the ESP32 resolves its state and publishes over Wi-Fi to an MQTT broker; a Bluetooth LE channel gives local control even with no network.
- **Decide** — an automation flow (n8n / Node-RED / custom) subscribes and drives dashboards, alerts, and logs.

3.3 Theory of operation

1. **Device identity.** On boot the device derives its identity from the module's MAC: the MQTT id `5tech-bridge-a1b2c3` and the BLE name `5Tech-IoT-Bridge-a1b2c3` (last six MAC hex digits).
 2. **State machine.** Nine states — `BOOTING`, `WIFI_CONNECTING`, `MQTT_CONNECTING`, `READY`, `WARNING`, `DANGER`, `OFFLINE`, `CONFIG_MODE`, `ERROR`. Once operational, the state is resolved in strict priority: `error > danger > warning > config_mode > !wifi > READY`. Each state has its own onboard-LED blink pattern.
 3. **Latching hazards.** Hazard levels are ordered `NORMAL < WARNING < DANGER`. Raising to a higher level wins and publishes an event; raising to an equal or lower level is a no-op. A hazard **latches** — a recovering sensor does **not** auto-clear it. Only an explicit `clear` (or a configured timeout, off by default) returns to `NORMAL`.
 4. **Publishing.** Telemetry publishes every 5 s, an event publishes immediately on any change, and status is retained on the broker with a Last Will so a late subscriber always sees the true state. A hazard outranks connectivity: a device in `DANGER` keeps reporting `DANGER` even if Wi-Fi drops.
 5. **Commands.** The same command grammar works on serial, Bluetooth LE, and MQTT. Commands are queued and executed on the main loop, never on a radio callback task.
-

4. Controls & indicators




Figure FIG-004 — Pins, the onboard button, the status LED, and the USB connector, with a numbered legend.

Exact pin numbers are the Phase-1 defaults; confirm against the datasheet and your board's silkscreen.

CONTROL / INDICATOR	FUNCTION	STATES
USB connector	Power, flashing, serial console (115 200 baud)	Connected / disconnected
Status LED (<code>GPI02</code>)	Device state	A distinct blink pattern per state (READY, WARNING, DANGER, OFFLINE, CONFIG_MODE, ...)
Button (<code>GPI00</code> , onboard BOOT)	Manual trigger	Short press = raise warning / clear an active hazard · Long press (≥1.5 s) = raise danger
Det1 input (<code>GPI018</code>)	Digital input, active-low	Asserted → WARNING; value mirrored over BLE
Det2 input (<code>GPI019</code>)	Digital input, active-low	Asserted → DANGER; value mirrored over BLE
Con1 output (<code>GPI023</code>)	Remotely settable contact	Set over BLE / MQTT / serial (<code>set_con1 0\1</code>)
Buzzer (<code>GPI025</code> , optional)	Local annunciation	Disabled by default (<code>ENABLE_BUZZER = 0</code>)

NOTICE. On most ESP32 devkits `GPI02` is the onboard LED. Phase-1 uses it for device state, so `Con1` was moved to `GPI023`. To restore the original wiring, set `CON1_GPIO = 2` and `ENABLE_STATUS_LED = 0` (a compile-time guard enforces that they never share a pin).

5. Operation

5.1 Before you start

You need: an ESP32-WROOM-32 dev board, a data-capable USB cable, a host computer with the toolchain, and (for the Wi-Fi/MQTT path) an MQTT broker such as `mosquitto` on the same trusted LAN. No sensor hardware is required.

Two firmware variants are available and are interchangeable on the wire:

ESP-IDF VARIANT		PLATFORMIO / ARDUINO VARIANT
Toolchain	ESP-IDF (builds on v5.4.4)	PlatformIO (builds on 6.1.19)
Build	<code>idf.py build</code>	<code>pio run</code>

Full toolchain setup is in `modules/5tech-edge-iot-bridge/docs/setup.md`.

5.2 Configure secrets and flash

NOTICE. `secrets.h` is gitignored and must never be committed. Only `secrets.example.h` is tracked.

ESP-IDF variant:

1. Copy the template: `cp firmware/esp-idf/main/config/secrets.example.h firmware/esp-idf/main/config/secrets.h`
2. Edit `secrets.h` — set `WIFI_SSID`, `WIFI_PASSWORD`, and `MQTT_HOST`.
3. Build and flash: `cd firmware/esp-idf && idf.py set-target esp32 && idf.py build`
4. `idf.py -p /dev/ttyUSB0 flash monitor`

Arduino / PlatformIO variant:

1. `cp firmware/platformio/src/config/secrets.example.h firmware/platformio/src/config/secrets.h`
2. Edit `secrets.h` as above.
3. `cd firmware/platformio && pio run && pio run -t upload`
4. `pio device monitor`

5.3 First power-on and status check

1. Connect the board over USB and open the serial monitor at **115 200 baud**.
2. Confirm the device prints its identity (`5tech-bridge-...`) and begins its boot sequence.
3. Watch it associate with Wi-Fi, connect to the broker, and start Bluetooth LE advertising.
4. Confirm the status LED settles into the `READY` pattern.
5. If Wi-Fi does not connect within ~15 s the device continues **offline**: BLE and serial keep working and the state reads `OFFLINE`. This is expected, not a fault.

5.4 Bench mode (no Wi-Fi)

Leaving `WIFI_SSID` at its placeholder is a **supported bench mode**: the device skips Wi-Fi, boots into `CONFIG_MODE`, and stays fully usable over Bluetooth LE and the serial console. Every command works; only MQTT publishing is unavailable.

5.5 The demo flow

1. On a laptop on the same LAN, subscribe to the broker: `mosquitto_sub -h <broker> -t "5tech/iotbridge/+/#" -v`
2. Trigger a warning — from the serial console, from a phone over Bluetooth LE (write `test_warning` to the **Cmd** characteristic), or by publishing to the command topic. All three are equivalent.
3. Watch `[STATE] READY -> WARNING`, the LED cadence change, and the event land on the broker.
4. Trigger `test_danger`. The LED goes faster and the danger **latches**.
5. Send `clear`. The device returns to `READY`.
6. Explain the point: only the trigger is simulated — swap it for a real sensor and nothing downstream changes.

5.6 Orderly shutdown

Simply unplug USB. On an ungraceful disconnect the broker publishes the retained **Last Will**, so the device's status flips to `OFFLINE` for any subscriber. On the next boot the device overwrites it with a live status.

6. Configuration

6.1 Configuration methods

METHOD	USE	NOTES
<code>secrets.h</code> (build-time)	Wi-Fi and broker credentials	Gitignored; requires a re-flash
Feature flags (build flags)	Enable/disable subsystems	<code>#ifndef</code> -guarded; override with <code>-D</code>
Runtime commands (serial / BLE / MQTT)	Trigger events, set thresholds, drive <code>Con1</code> , reboot	Identical grammar on all three transports

6.2 Runtime commands

Accepted as bare text **or** JSON, on any transport.

COMMAND	EFFECT
<code>help</code>	List commands
<code>status</code>	Current status, as JSON
<code>config</code>	Running configuration, as JSON
<code>test_warning</code>	Raise a <code>WARNING</code> event
<code>test_danger</code>	Raise a <code>DANGER</code> event
<code>clear</code>	Clear the active event
<code>set_threshold <n></code>	Set the danger threshold (JSON form can move both bounds)
<code>set_con1 <0\ 1></code>	Drive the Con1 contact
<code>reboot</code>	Restart (the reply is flushed first)

Examples:

```
test_danger
{"command": "set_threshold", "danger_threshold": 40, "warning_threshold": 90}
```

6.3 Thresholds

The sensor value is modelled as a **distance in cm** — smaller means closer means worse. A reading below `warning_threshold` (default 100) raises WARNING; below `danger_threshold` (default 50) raises DANGER. `set_threshold` rejects any pair where warning is not strictly above danger or that leaves the valid range `[0, 200]`. **Thresholds are not persisted** — a reboot restores the compiled defaults.

6.4 Bluetooth LE commands

1. Scan for `5Tech-IoT-Bridge-...`, or filter on the service UUID `4fafc201-1fb5-459e-8fcc-c5c9c331914b` (more reliable — the name is in the scan response).
2. Connect and expand the custom service.
3. **Enable notifications on the `Resp` characteristic before writing to `Cmd`.** Replies to an unsubscribed `Resp` are dropped — this is the most common cause of "no response".
4. Write a command as UTF-8 text (e.g. `test_danger`) to `Cmd`. Replies arrive as notifications on `Resp`, shaped `OK <cmd>: <message>` or `ERR <cmd>: <message>`.
5. Write `0x01` (a raw byte, not the text "1") to `Con1` to drive `GPI023` high; `0x00` drives it low.

6.5 Firmware update

Flash over USB (\$5.2). There is **no OTA and no BLE update** in Phase 1.

7. Maintenance

The Edge Bridge is firmware on a development board; there are no scheduled physical maintenance tasks. "Maintenance" here means keeping the firmware and its configuration sound.




Figure FIG-005 — Points of routine attention: the USB connection, the secrets file, and the automated test suites.

INTERVAL	TASK	NOTES
As needed	Re-flash after a firmware change	\$5.2
As needed	Keep <code>secrets.h</code> current and uncommitted	Verify with <code>git check-ignore</code>
Before tagging a build	Run the host test suite (<code>make -C tests/host</code>)	77 assertions, no hardware
Before tagging a build	Run the wire-parity check	Confirms both variants still agree
Routine	Inspect the USB cable and connector	A charge-only cable is a common failure
Routine	Keep the board dry, static-safe, and clear of shorts	Bare PCB, no enclosure

8. Troubleshooting

SYMPTOM	POSSIBLE CAUSE	ACTION
No serial output	Wrong baud or charge-only cable	Use 115 200 baud and a data cable; confirm the serial port
No BLE response to a command	<code>Resp</code> notifications not enabled	Enable notifications on <code>Resp</code> before writing <code>Cmd</code> (§6.4)
Device not on the broker	Wrong <code>MQTT_HOST</code> , broker down, or wrong port	Check <code>secrets.h</code> , confirm the broker on port <code>1883</code> , check the LAN
Stuck in <code>CONFIG_MODE</code>	Placeholder or missing Wi-Fi credentials	Set real <code>WIFI_SSID</code> / <code>WIFI_PASSWORD</code> in <code>secrets.h</code> and re-flash
State reads <code>OFFLINE</code>	Wi-Fi not connected	Expected without Wi-Fi; BLE and serial still work; check credentials/coverage
Broker shows the device <code>OFFLINE</code>	Last Will fired on an ungraceful disconnect	Normal after power loss; it self-repairs on reconnect
Hazard will not clear	Latching hazard model	Send <code>clear</code> explicitly — a recovering sensor does not auto-clear (§3.3)
<code>Con1</code> seems to toggle the LED	<code>Con1</code> on <code>GPI02</code> (original wiring)	Phase-1 uses <code>GPI023</code> ; see the §4 NOTICE
BLE stutters under load	Wi-Fi and BLE share one antenna	Expected on ESP32; reduce Wi-Fi load during BLE work
ESP-IDF build fails on partition size	App overflows the default 1 MB partition	Use <code>CONFIG_PARTITION_TABLE_SINGLE_APP_LARGE</code> (Arduino: <code>huge_app.csv</code>)
A command is silently dropped	Command queue (depth 8) full	Reduce command rate; the drop is logged on serial

If a fault persists, capture the serial log, the `status` / `config` output, and the broker messages, then consult the engineering docs in `modules/5tech-edge-iot-bridge/`.

9. Specifications

This manual does **not** duplicate specification values. All dev-board, interface, electrical, and environmental specifications are held in the datasheet:

- **Datasheet:** <datasheets/esp32-edge-bridge-datasheet/document.md>

AREA	WHERE TO FIND IT
Hardware platform (ESP32 dev board)	Datasheet §1, §4
Mechanical (form factor)	Datasheet §5
Electrical (USB power, logic level)	Datasheet §6
Interfaces & protocols (Wi-Fi, BLE, MQTT, GPIO, serial)	Datasheet §7
Environmental & ratings	Datasheet §8
Compliance (n/a — development prototype)	Datasheet §9

10. Warranty & support

Warranty. This is a **Phase-1 MVP / development prototype**, provided as-is for evaluation and demonstration. It carries no commercial product warranty and no certification. Production warranty terms are [\[TBD\]](#) and belong to Phase 2.

Support.

- 5Tech — Vancouver, BC, Canada
- Email: info@5tech.ca
- Web: <https://5tech.ca>

When contacting support, have ready: the firmware variant and version, the device id ([5tech-bridge-...](#)), the serial log, and the broker messages around the issue.

NOTICE — Not a safety device. Do not deploy this prototype in any role where a failure could harm people or equipment. It is a monitoring and automation MVP, nothing more. (A scope advisory — a [NOTICE](#) per §1.1, not a hazard warning about the device itself.)

Figures

ID	TITLE	STATUS	FILENAME	PURPOSE
FIG-001	Edge Bridge — Prototype Hero Render	Missing	renders/hero_edge-bridge.png	Manual cover / hero
FIG-002	Safety Symbols & Signal Words	Missing	figures/safety_symbols.png	Signal words and pictograms for the safety chapter
FIG-003	Product Overview	Missing	figures/overview.png	Orient the user to the board and its connections
FIG-004	Controls & Indicators	Missing	figures/controls_indicators.png	Identify pins, the button, the LED, and the USB connector
FIG-005	Maintenance Points	Missing	figures/maintenance_points.png	Locate points of routine attention

This manual is preliminary and subject to change. See [revision.md](#) for change control, [references.md](#) for sources, and [image_prompts.md](#) for the figure/prompt index.